

SC-A10 Manual

User



SC-A1

Advanced weighing equipment with ABS or INOX finish, backlit LCD display with 3 numeric display fields and alphanumerical keyboard.



2017-02-14

COMPLETE USER MANUAL

Features

- ⊕ **Weight-Tare-Piece counter** with possibility of **options and add-ons**.
- ⊕ **Keys exclusively for the** classic weighing system, similar to previous units, in the line of **SC10**.
- ⊕ **Clear, intelligible** weighing **symbols** for improved, more **convenient reading** of the data displayed.
- ⊕ Printing of **weight** on the platform with **large, notable size**.
- ⊕ **Clock/Calendar** fitted as standard.
- ⊕ Quicker weighing **system** optimized for greater **fluidity, accuracy** and exactness.
- ⊕ **Intuitive** menu system.
- ⊕ Enter menu with fully configurable, flexible **scale, fraction** and **decimals**.
- ⊕ **Auto-calibration** without having to re-adjust the weight when changing scales.
- ⊕ **On/off** by key.
- ⊕ Option to **manually set** the weight, for optimal, quick calibration.
- ⊕ **Piece counter** function with more than **a million internal** points.
- ⊕ Dedicated **animal weighing function** as standard.
- ⊕ Smart **display-repeater function**, with possibility of repeating most **market protocols**.
- ⊕ **Extended accumulation**: millions of accumulations with 64 bit totaliser.
- ⊕ **Standard manual tare**.
- ⊕ **Accumulation** and **auto-accumulation** of serial weighings.
- ⊕ **Automatic totalling** of serial weighings.
- ⊕ **Accumulated Grand Total**.
- ⊕ Configurable number of **lines** to finish ticket and delays per printed line.
- ⊕ **Repeat ticket** and optional **ticket per weighing**.
Note: If the equipment shuts down with an open ticket, when restarting the equipment will continue with the ticket but can not be repeated, unless the equipment has DSD memory, in which case the ticket may be repeated using the option DSD in the user menu.
- ⊕ Dedicated selectable connection to the **most used printers**.
- ⊕ **Label** printing function (connection to Godex and Zebra labeller).
- ⊕ Possibility of serial communications up to **115200 baud rate**, N81, E71 and O71.
- ⊕ **Self-test of the default serial communication channels**.
- ⊕ Continuous programmable **send time**.
- ⊕ Optional **auto-zero in negative** to prevent zero errors of the scales in hostile environments.
- ⊕ Energy-saving and optimisation measures: **low consumption mode and programmable power-off due to inactivity**.
- ⊕ **Transfer of external data** and configuration **from PC** of the display parameters.
- ⊕ Battery status **indicator** (in versions with battery).
- ⊕ Possibility of **independent auto-calibration** of each display.
- ⊕ **Multirange** totally programmable, flexible twin scales.
- ⊕ **Linearisation** up to 16 points which can be easily defined by the user.
- ⊕ GROSS-TARE-NET special **discharge function** ticket as standard.
- ⊕ Large selection of **compatible printers** with optional auto-cutter.
- ⊕ **Auto-calibration** of analogue cell systems
- ⊕ **Customer-programmable password**.
- ⊕ **SENSORED** communication system and **network connection** of indicators (for RS485 wired networks) for customized weighing applications
- ⊕ **6 languages**: Spanish, Portuguese, French, Italian, English and German.
- ⊕ Includes USB connector for standard PC keyboard.

INDEX

1	KEYBOARD	- 4 -
2	FUNCTIONS MENU	- 5 -
3	DISPLAY LCD.....	- 8 -
4	INSTRUCTIONS AND GENERAL OPERATION MODE.....	- 9 -
4.1	Ordinary weighing (Net/gross tare, tare lock)	- 10 -
4.1.1	Quick zero:.....	- 11 -
4.1.2	Stability.....	- 11 -
4.1.3	Quick tare	- 12 -
4.1.4	Gross weight/net weight:.....	- 13 -
4.1.5	Tare lock	- 13 -
4.1.6	Quick Manual Tare (*):	- 14 -
4.2	Memorized Tares (*)......	- 15 -
4.3	Quick selection code.....	- 16 -
4.4	Extended accumulation and totalisation of weighings	- 17 -
4.4.1	Manual accumulation.....	- 17 -
4.4.2	Automatic accumulation	- 19 -
4.4.3	Totalise	- 19 -
4.5	Piece counter	- 21 -
4.5.1	Accumulation and totalisation	- 21 -
4.6	Units with Battery	- 22 -
4.7	Equipos con memoria DSD (Aliby)	- 22 -

1 KEYBOARD

The diagram shows a scale control panel with a large LCD display and a numeric keypad. The display shows '0.000 Kg' and 'Total 2.045 Kg'. Below the display are several function keys: ON/OFF, T (Tare), B (Zero/Gross), FUN (Function), and INTRO (Intro/Print). The numeric keypad includes digits 0-9, function keys F1-F4, and a central directional pad. A legend on the right explains the functions of the numeric keypad and function keys.

NUM: Numeric keyboard

C: Delete figure, number or literal.

F: Validate figure, number, literal, option.

F1: Totalize

F2: Tares / Codes

F3: Rapid Manual Tare/ Piece Counter

F4: User Menu

ON / OFF: Turn ON / Turn OFF	T: Tare	B: Zero / Gross	FUN: Function (auxiliary)	INTRO: Intro / Print	UP: Up / Increm.	LEFT: Exit / Return	DOWN: Down / Decrem.	RIGHT: Enter / Change Option
--	-------------------	---------------------------	-------------------------------------	--------------------------------	----------------------------	-------------------------------	--------------------------------	--

Environment	Key	Descriptions (standard functions)
Always	ON/OFF	With the equipment power off, pressing the key turns the equipment ON . With the equipment power on, long press the key (more than 2 seconds) turns the equipment OFF .
Direct access	F1	TOTALIZE . With relay option will enter in RELAY MENU .
	F2	Selection/Edition of SAVED MANUAL TARE with numeric code (up to 255). Edition of UNIT WEIGHT PIECE COUNTER (if active).
	F3	Switches the display between WEIGHT and PIECES (if active). QUICK MANUAL TARE in weight mode.
	F4	Key for direct Access to the FUNCTIONS MENU .
Weighing	T	Carries out TARE / TARE LOCK (2 quick press of T key) / TARE UNLOCK .
	B	ZERO is set. If there is a tare, the weight display mode is: NET / GROSS .
	FUN	SPECIAL FUNCTION key to combine with any of the others: - INTRO: TOTALISE in the Relay Programs.
	INTRO	The weighing is ACCUMULATED and PRINTED through RS232. If there is an active dosing program, the START function is carried out.
Flechas: Pesaje/ Navegación por códigos	UP	Moving between menus, allows to move to the next menu in the navigation
	LEFT	LEAVE the menu or option.
	DOWN	Moving between menus, allows to move to the previous menu in the navigation
	RIGHT	ENTER the submenu or change the option.

2 FUNCTIONS MENU

To enter: F4
(The optional ones are shaded)

<i>Option</i>	<i>Description</i>	<i>Actions</i>
➤ -CODE-	Code of weighing in progress.	(0.. 255) NUM to modify code (numeric or alphanumeric) C delete flashing digit. UP/DOWN to increase/decrease the numeric code. F2 to change between numeric and alphanumeric code. F to select/validate/save the code. LEFT to exit without saving.
➤ N.LABEL. (**)	Label number.	(0.. 255) (The label 255 corresponds to the Total). NUM to enter the label number. F to validate/save the code. LEFT to exit without saving. (Appears only when in the Programming Menu some labeler have been selected). <i>NOTE: See Programming Manual for more information.</i>
➤ TICKET(***)	Delivery note number.	(6 decimal digits). NUM to enter the number of Ticket/Delivery. C delete flashing digit. F to validate/save the number of Ticket. LEFT to exit without saving. If 0, it will not appear in the ticket. Otherwise it will increase automatically. (Does not appear on equipment with the DSD option)
➤ TIK.REP.	Repeat ticket	(0.. 15 automatic tickets). UP/DOWN to increase/decrease value. NUM to edit value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving. Each time a ticket is closed, proceed in accordance with the values: -0: Normal operation. -1: You will be asked whether to repeat the ticket. -2..15: There will be as many tickets as the value.
➤ SUBTOT	Shows the accumulated weight subtotal so far.	It shows the number of total accumulated weighings and the total weight of the current ticket or the previous one if it is been already closed. It leaves the option after displaying the number of weighings and the accumulated weight.
➤ AUTOAC	Auto-accumulation when stability is reached.	(Yes/No) UP/DOWN to change between Yes/NO. F to validate/save the option. LEFT to exit without saving.
➤ AUT.TAR	Auto Tare when stability is reached after passing through zero.	(Yes/No) UP/DOWN to change between Yes/NO. F to validate/save the option. LEFT to exit without saving.
➤ NU.ACUM(*)	Number of accumulations before automatic totalling.	(0.. 255 accumulations). UP/DOWN to increase/decrease value. NUM to edit value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving.
➤ W.UNIQ.	Single weighing mode selection.	(Yes/No) UP/DOWN To change between Yes/NO. F to validate/save the option. LEFT to exit without saving. There will be a complete ticket for each weighing (and also when totalising weighing).

➤ BIG.TOT	Grand Total. Shows the accumulated weight total since the last time its value was reset.	It shows the grand total of accumulated weighings and the grand total accumulated weight. INTRO to show the accumulated grand total. INTRO during scroll: Prints and deletes the accumulated grand total.
➤ F.WEIGHT	It displays the maximum weight. When pushing [INTRO] the memorized weight is erased and recalculates a new maximum.	(Yes/No) UP/DOWN To change between Yes/NO. F to validate/save the option. LEFT to exit without saving.
➤ HI-RES	High resolution. Shows the weight with another precision digit (Weight x 10)	Displays weight in high resolution. (x10) B performs a ZERO in equipment. LEFT to exit.
➤ PIECES	Advanced piece counter. Selects Piece counter mode	(Yes/No) UP/DOWN To change between Yes/NO. F para validar/grabar opción. LEFT para salir sin grabar. Al habilitarlo, en modo peso: F3 Cambia entre piezas y peso. F2 Para introducir el número de piezas que se están pesando (el equipo calculará el peso unitario)
➤ DISCHA. (*)	Accumulation in download. Process (once in weight mode): 1- With full container press I . 2- Empty container and press INTRO . (repeat process until finishing with FUN + INTRO)	(Yes/No) UP/DOWN To change between Yes/NO. F to validate/save the option. LEFT to exit without saving.
➤ ANIM.WE. (*)	Dynamic weighing for animals	RIGHT to enter submenu. LEFT leave submenu. UP/DOWN to navigate inside submenú.
➤	--ON--	(Yes/No) UP/DOWN To change between Yes/NO. F to validate/save the option. LEFT to exit without saving. A very large number of weight samples will be carried out at high speed to calculate and display the average at the end of the process.
➤	LOW.BOW.	Inferior limit of weight (6 digits). NUM to enter value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving. -Weight values below this value are rejected. With AUTOMA=YES, waiting time T.INI is initiated when the weight exceeds this value.
➤	HIG.BOW	Upper weight limit (6 digits). NUM to enter value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving. - Weight values above this value are rejected.
➤	INIT.T.	With AUTOMA=YES. Waiting time before initiating the process of sample weight. (0.. 25,5 seconds). NUM to enter value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving.
➤	AWG.TIM	Time duration of the sampling weight. (0 .. 25.5 seconds). NUM to enter value. C delete flashing digit. F to validate/save the value. LEFT to exit without saving.
➤	AUTOMA	(Yes/No) UP/DOWN To change between Yes/NO. F to validate/save the option. LEFT to exit without saving. Yes -> Weight sample is automatically initiated once INIT.T. time is passed after the weight value defined in


	LOW.BOW is exceeded. No -> The equipment waits for the pressing of INTRO key to initiate the process of weight sample. (It does not wait for INIT.T. even though the LOW.BOW is exceeded).
➤ CLOCK	Shows/Sets the clock and calendar. RIGHT to access submenu.
	TIME Displays and enables modification of current time. (HH:MM:SS) LEFT/RIGHT to change the flashing digit. UP/DOWN to change the value of the flashing digit. F to validate/save Time. FUN to exit without saving.
	DATE Displays and enables modification of current date. (DD.MM.AA). LEFT/RIGHT to change the flashing digit. UP/DOWN to change the value of the flashing digit. F to validate/save Date. FUN to exit without saving.
➤ CELLS	Show counts and weight of each load cell. (Only in equipment with communication with digital load cells) Load cell number selection mode. UP/DOWN to increase/decrease number. F or DER to validate number and move on to reading mode.
	CEL. xx (load cell selection with I /B) Read Mode. UP/DOWN to change load cell. LEFT switches to the load cell number selection mode RIGHT to switch between counts and weight.
➤ -DSD- (*)	Consult and print data saved in DSD memory. (Only in equipment with DSD) Ticket number selection mode. NUM to enter number. UP/DOWN to increase/decrease number. C delete flashing digit. F2 to validate number and move on to detail mode.
	It shows the net weights of the different accumulations registered in the selected Ticket and also print a copy of the Ticket. Detail Mode. UP/DOWN to navigate through the different accumulations recorded and the Total accumulated. LEFT switches to the Ticket number selection mode. INTRO/PRINT prints a copy of the selected Ticket.

(*) This option **DOES NOT** appear if there is an open ticket. (Close ticket by pressing **FUN + I** in Weight mode)

(**) This option **DOES NOT** appear if any communication **PORT** of the equipment no has not been configured to connect to the labelling machine. (See option **-COM-** from Programming menu).


(***) This option **DOES NOT** appear if the equipment has DSD. (With DSD option the equipment does not allow manual modification of the number of Ticket / Delivery Note)

3 DISPLAY LCD



4 INSTRUCTIONS AND GENERAL OPERATION MODE

When starting up the unit, the ON/OFF key can be pressed to carry out an initial test, showing all the display's digits and pilots.




The equipment identifier is then displayed:



Then, if the equipment has dead weight (units with weight module or digital cell communication), the counter value is shown the number of times the unit's metrological (weight) parameters have been modified.




Finally, a message (banner type) describing the different functions of the unit is displayed.




Both the text of the banner displayed when starting up the unit and the headers and footers of the tickets can be defined by the user using the SENSODATA program.

Once complete, the unit returns again to weight mode and shows the measured weight (The equipment performs a “0” when starting up”).



4.1 Ordinary weighing (Net/gross tare, tare lock)

By defect, the unit will start up showing the weight on the platform:




4.1.1 Quick zero:

Whenever, without any weight on the platform, the unit shows a weight value other than zero.



The zero should be manually corrected by pressing the **B** key.



The machine can automatically reset at start-up enabling the INIT.Z option in the WEI.OPT. programming submenu.

4.1.2 Stability

The display shows the measured weight variations. The speed with which the changes and the degree of weight stability shown are displayed depend on the values set in the filter parameters. (Options **STAB.T**, **FILTER** and **FIL.DEP** in the Programming Menu).

As soon as the weight stabilises, the display activates the stability pilot (☒) to indicate the condition of stable weight.



Most of the actions carried out by the display (tare, print ticket, start load or discharge of dose, etc.) are associated with stable platform condition (stable weight).

4.1.3 Quick tare

Pressing the **I** key when the unit shows stable weight other than zero causes the unit to tare the weight on the platform, making the weight value displayed on screen pass to 0 and activating the pilot **NET**.



As of this moment, the display shows the net weight whenever the platform weight changes.


Whenever the net weight displayed is not zero, pressing the **I** key again causes the unit to carry out a new Tare.

The Quick Tare function it's only available when the number of divisions of gross weight is bigger than the one defined in the minim weight option (WEI.MIN) in the WE.CTR programming submenu.


4.1.4 Gross weight/net weight:

With the unit tared, pressing the **B** key allows switching between net weight and gross weight on the display.

To indicate that the weight shown on the display corresponds to gross, enable both the **B** pilot and the **NET** pilot:




Tare is automatically disabled when all the weight is removed from the platform, deleting and re-displaying the gross weight:



4.1.5 Tare lock

To prevent tare from being disabled when all the weight is removed from the platform, press the **I** key a second time when the net weight shown is zero (pressing once tares the weight, and pressing twice locks tare).

Locking the tare activates the unit's **>T<** pilot in order to indicate locked tare. As of this moment, and always when the net weight shown is zero, the **I** key can switch between tare and tare locked modes.




The tare lock function is only available if initial zero option (INIT.Z) has been enabled in the WE.CTR programming submenu.

4.1.6 Quick Manual Tare (*):

The system allows to define a value of quick manual tare. To do this without leaving the weight mode, you must press the **F3** key (**This option does not work if the piece-counting mode is enabled**). When doing so, the equipment enters in editing mode of manual tare showing a tare value with the rightmost digit flashing. To change the tare value shown, use the alphanumeric keypad, with the key **LEFT** we leave without validating and the key **E** validate the tare value introduced, doing a Tare in the equipment while Tare gets blocked.

For example, with a weight of 7.112 we enter a manual tare 1,538, after validating the **E** key on the display will be shown:



When manual tare is activated, the printing of tare on a ticket is accompanied by the symbol "PR" to indicate that the weighing is carried out with a manual tare.

=====			
N.PES.	CODIGO	TARA kg	NETO kg
=====			
1		PR: 1.538	5.574

(*) The F3 function key to enter manual tare is NOT available in the following cases:

- If are activated any of the following options: limits, semaphore or any dosage (options available via the submenu APLICA of the programming menu)
- If the mode Piece-Counter is activated (option available via the submenu option PIECES of the user menu)

4.2 Memorized Tares (*)

To edit and/or select a tare associated with a tare number, press **F2**. Doing so, in the auxiliary display 2 is shown the preset tare corresponding to the number of tare shown on auxiliary display 3 with the rightmost digit flashing. We can change this tare number using the alphanumeric keypad **NUM** or increase / decrease its value with the **UP/DOWN** keys.

Within the menu of memorized tares, pressing the **F2** key allows us to toggle between editing modes of tare number and preset tare.



By last with the **LEFT** key exits the menu without selecting or record anything and with the **E** key the memorized tare is selected or only it is recorded if it has been modified (in this last case, with a second pressing of the **E** key we exit selecting the new tare).



With an active preset tare, pressing the **T** key does not swing between tare and locked tare, but allows to tare again the weight pressing it when desired, saving at the same time as the value of memorized tare associated with the number of tare active in that moment. From this point functionality will be restricted to the *tare blocking* section.

The value of manual tare will be printed on the ticket preceded by the symbol "PT", indicating the nature of the tare.


N.PES.	CODIGO	TARA kg	NETO kg
1		PR: 1.538	5.574

(*) The F2 function key to enter memorized tares is NOT available in the following cases:

- If are activated any of the following options: limits, semaphore or any dosage (options available via the submenu **APLICA** of the programming menu)
- If the mode Piece-Counter is activated (option available via the submenu option **PIECES** of the user menu)

4.3 Quick selection code

The equipment allows to select an alphanumeric code directly simply by typing its number in the **NUM** alphanumeric keypad or using the **UP / DOWN** keys to change to the previous / following code shown in the auxiliary display 3.



4.4 **Extended accumulation and totalisation of weighings**

The unit can account for weight (accumulate weighings), using the data to print a ticket per printer and/or label and/or send the weighing data through the serial communication ports (**PORTS**).

The unit allows individual weighings (printing a ticket for each weighing) or multiple weighings (with several weighings in the same ticket and finalised with a total) to be done automatically (when detecting stable weight on the platform) or manually (by pressing the **INTRO** key when the unit displays stable weight).

Three conditions must be met in order for the unit to account for a weight (carry out weighing): there must be stable weight, which exceeds the value defined as minimum weighing (*), with the weight dropping below the minimum weight necessary to carry out weighing at some point since last weighing (i.e. the last weighing has been discharged).

Single weighing is selected using the W.UNIQ. option in the Functions menu.

Automatic weighing mode is selected using the AUTOAC option in the Functions menu.

(*) The minimum weight value for a weighing is determined using the WEI.MIN option in the unit's Programming menu.


4.4.1 **Manual accumulation**

In order to carry out manual accumulation, press the **ENT** key when the unit shows a stable weight value above the value defined as minimum weighing.


The following example assumes a stable weight of 1,754 kg, which we have previously tared manually at 1,538 kg. ($1754 - 1538 = 0.216$) and the active code is "HIERRO".



Start manual weighing by pressing the **ENT** key until the message **-ACC-** is shown in the display:



In the display auxiliary 2 is shown the number of weight performed, in the display auxiliary 3 the subtotal of weight accumulated so far.



If the unit is connected to a printer, and, for example, the code "100350" has been entered (using the **-CODE-** option in the functions menu), the following ticket will have been printed:

N.WEIGH.	CODE	TARE kg	NET kg
1	100350	* 1.538	0.216

To perform a new weighing and continue to accumulate, we remove the weight on the platform and place on it the new weight to accumulate, we wait until it is stable and again press the **ENTER** key.

If the code introduced is 0 (default value when starting up the unit), nothing appears in the CODE field of the ticket.

At the same time, if a PC connection has been configured in any of the serial communication PORTS with **MANUAL** send, pressing the **I** key causes a frame to be sent with the weight on the platform at this moment.

All the unit's serial communication PORTS can be configured (from the -COM-programming submenu) to connect to a printer, a labeller, a repeater or a PC in order to send weights.

In order to carry out a new weighing and continue accumulating, remove the weight from the platform and place the new weight to accumulate on it; wait for the weight to be stable and then press the **ENT** key again.

4.4.2 Automatic accumulation

Automatic accumulations do not require the **INTRO** key to be pressed for weighing; the unit simply has to detect a stable weight value greater than the value defined as minimum weighing (*) after the last weighing has been discharged.

Automatic weighing mode is selected using the AUTOAC option in the Functions menu.


(*) The minimum weight value for a weighing is determined using the WEI.MIN option in the unit's WE.CTR. programming submenu.

4.4.3 Totalise

To finish and totalise all the weights in process, it is necessary to press the **F1(*)** key or the **FUN** and **INTRO** keys simultaneously.

(*) The F1 function key to totalise and complete weighing is NOT available if are activated any of the following options: limits, semaphore or any dosage (options available via the submenu APLICA of the programming menu)

In the case, for example, there have been made 4 weighings with a total weight of 0.632 Kg, the equipment shows the number of weighings and the total accumulated in the auxiliary displays 2 and 3 respectively.



If the unit is connected to a printer, the ticket will finish, as in the following example:

N.WEIGH.	CODE	TARE kg	NET kg
1	HIERRO	1.538	0.216
2	HIERRO	0.000	0.252
3	COBRE	0.000	0.083
4	PLATA	0.252	0.081
TOTAL WEIGHINGS		TOTAL WEIGHT kg	
4			0.632



In this example, the following operations have been carried out in the ticket:

- Code HIERRO has been entered.
- A container of 1.538 kg has been tared.
- A weight of 0.216 kg has been entered and accumulated.
- The weight and the container have been removed.
- A weight of 0.252 kg has been entered and accumulated.
- The weight of the platform has been removed.
- The code COBRE has been selected.
- A weight of 0.083 kg has been entered and accumulated.
- The weight of the platform has been removed.
- The code PLATA has been selected.
- A weight of 0.333 kg has been introduced.
- A memorized tare of 0.252 kg has been selected.
- An accumulation has been performed.
- Totalised by pressing **FUN+ENT**.

The unit can carry out and memorise up to 255 weighings before totalising, and can accumulate a weight total of over 18 trillion weight units (kg, lb) and a Grand Total of over 60,000 weighings.

4.5 Piece counter

The piece counting mode can be enabled entering in the option "PIECES" in the functions menu of the device. When the equipment is running in piece counting mode, the value displayed is the result of the division between the measured weight and unit weight of each piece.



4.5.1 Accumulation and totalisation

Accumulation and aggregation in piece counting mode is performed in the same way as in ordinary weighing; accumulate pressing the [**ENTER**] key and we totalise with [**FUN + ENTER**]. The resulting ticket from operations with pieces has the following format:

```

=====
P.Unit:                                     0.0013
=====
N.PES.   CODIGO   NETO kg   PIEZAS kg
=====
      1           0.251     195
      2           0.123      95
=====
T. PESADAS                               PIEZAS
=====

```

In it this ticket is indicated the unit weight of the pieces, the weight and number of pieces of each weighing and total of pieces totalised.

Each time you change between weight / pieces (by pressing the **F3** key), the corresponding ticket will automatically close.

4.6 Units with Battery

Whenever the unit is battery-operated and this is below the correct threshold value, the corresponding indicator will come on and the screen will show the following message:



Automatically, the display illumination will be reduced to the minimum and configured to go off after 5 minutes of non-activity.

As a precaution, if low battery is detected when starting up, the display will not come on, showing first the aforementioned literals.

4.7 Equipos con memoria DSD (Aliby)

Equipments with DSD memory record all weighings made in the equipment.

This memory cannot be erased and in case the memory is fully occupied, the equipment rewrites the information of the oldest weighings.


The information of the memory is organized depending on the number of Ticket to which the weighing belongs to.

Every ticket is made up with the weighings made from the Ticket opening until its finishing.

In the equipments with DSD memory (Aliby), the number of Ticket is auto-increased with each new finalized ticket, not being able to be modified by the user.



The **-DSD-** option from the functions menu allows consulting and printing a copy of each ticket made on the equipment. It displays the number of weighings, the total accumulated weight and the net weight of any of the ticket weighings.

When accessing the **-DSD-** option from the functions menu, the equipment requests the number of ticket displaying by default the last finished ticket, for example:



In case it does not find any associated weighing, the following message is displayed:



 <p>MINISTERIO DE ECONOMÍA, INDUSTRIA Y COMPETITIVIDAD</p>	<p>EXPEDIENTE N°</p> <p>162011001</p>	 <p>CENTRO ESPAÑOL DE METROLOGÍA</p>
---	--	---

CERTIFICADO DE ENSAYOS

Test Certificate

Revisión 7^a al certificado CEM-CY-01/0025-5.2

7th Revision to certificate CEM-CY-01/0025-5.2

Expedido a: <i>Issued to</i>	SENSOCAR, S.A. Pol. Ind. Can Parellada - c/ Géminis, 77 08228 Terrassa - Barcelona									
De acuerdo con: <i>In accordance with</i>	Párrafo 8.2.1 de la Norma Europea EN 45501:2015 relativa a los aspectos metrologicos de los instrumentos de pesaje de funcionamiento no automático, y a la Guía nº 2.1 de WELMEC. La fracción de error aplicada p_r , con referencia al punto 3.10.2.1 de la EN 45501, es de 0,5. <i>Paragraph 8.2.1 of the European Standard on Metrological aspects of non-automatic weighing instruments EN 45501:2015, and WELMEC 2.1. The applied error fraction p_r, with reference to paragraph 3.10.2.1 of this standard is 0,5.</i>									
Instrumento: <i>Instrument</i>	Indicador de peso para uso industrial, electrónico, de indicación automática, monoescalón y multiescalón, ensayado como parte de un instrumento de pesaje de funcionamiento no automático de clase de exactitud III y III . <i>The model of an indicator for industrial application, electronic, self indicating, single and multiple scale interval, tested as part of a non-automatic weighing instrument class III and III.</i>									
Especificaciones: <i>Features</i>	<table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">Número máximo de escalones (n) <i>Maximum number of verification scale intervals</i></td> <td style="width: 50%;">n ≤ 10000 para IPFNA de clase de exactitud III <i>n ≤ 10000 for NAWI accuracy class III</i> n ≤ 1000 para IPFNA de clase de exactitud III <i>n ≤ 1000 for NAWI accuracy class III</i></td> </tr> <tr> <td>Mínimo voltaje de entrada por escalón de verificación (<i>Minimum input-voltage per verification scale interval</i>)</td> <td>0,6 μV/e</td> </tr> <tr> <td>Voltaje del rango de medida (<i>Measuring range voltage</i>)</td> <td>5 mV - 15 mV</td> </tr> <tr> <td>Rango de impedancia (<i>Impedance range</i>)</td> <td>40 Ω a 2000 Ω</td> </tr> </table>		Número máximo de escalones (n) <i>Maximum number of verification scale intervals</i>	n ≤ 10000 para IPFNA de clase de exactitud III <i>n ≤ 10000 for NAWI accuracy class III</i> n ≤ 1000 para IPFNA de clase de exactitud III <i>n ≤ 1000 for NAWI accuracy class III</i>	Mínimo voltaje de entrada por escalón de verificación (<i>Minimum input-voltage per verification scale interval</i>)	0,6 μV/e	Voltaje del rango de medida (<i>Measuring range voltage</i>)	5 mV - 15 mV	Rango de impedancia (<i>Impedance range</i>)	40 Ω a 2000 Ω
Número máximo de escalones (n) <i>Maximum number of verification scale intervals</i>	n ≤ 10000 para IPFNA de clase de exactitud III <i>n ≤ 10000 for NAWI accuracy class III</i> n ≤ 1000 para IPFNA de clase de exactitud III <i>n ≤ 1000 for NAWI accuracy class III</i>									
Mínimo voltaje de entrada por escalón de verificación (<i>Minimum input-voltage per verification scale interval</i>)	0,6 μV/e									
Voltaje del rango de medida (<i>Measuring range voltage</i>)	5 mV - 15 mV									
Rango de impedancia (<i>Impedance range</i>)	40 Ω a 2000 Ω									
Fabricante: <i>Manufacturer</i>	SENSOCAR, S.A.									
Marca/modelo: <i>Trademark/Type</i>	SENSOCAR, S.A. / SC-AX									
Código CEM: <i>CEM code</i>	--									
Observaciones: <i>Comments</i>	Esta nueva versión del modelo SC objeto de la presente revisión, complementa a todas las versiones descritas en la revisión sexta									

Fecha de ensayos: 21/09/2016 al 18/11/ 2016

Este certificado establece la conformidad del equipo reseñado con los ensayos descritos en el anexo, en cuanto se refiere a las características técnicas y metrologías del equipo, no atribuyendo al mismo ninguna aprobación de carácter legal. Este certificado no puede ser citado en un Certificado de Aprobación CE de Modelo sin autorización del solicitante arriba indicado. No se permite la reproducción parcial de este certificado sin autorización expresa para ello.
This certificate establishes the conformity of the equipment above indicated with the test described in the annex, relating to the technical and metrological characteristics of the equipment. This certificate does not bestow any form of legal international approval. This test certificate cannot be quoted in an EC Type-approval certificate without permission of the applicant quoted above. Partial quotation of this certificate is not permitted without written permission.

***Electromagnetic susceptibility has been certified in tests conducted with field strength of 10 V/m, in accordance with new regulations.**